

## Swiftel Communications Cyber Power Information

AC and OUTPUT are on green  
Battery light is normally off



| Indicator | Color  | Condition   |
|-----------|--------|---|
| AC        | Green  | UPS is on utility power.  |
|           | Yellow | UPS is on battery power.  |
| OUTPUT    | Green  | DC output power is provided by the battery or utility power.      |
| BATTERY   | Red    | The battery is not connected or the battery needs to be replaced. |

System Status is on green  
Other Lights are normally off



| Indicator       | Color  | Condition  |
|-----------------|--------|--|
| SYSTEM STATUS   | Green  | Indicates normal mode of operation.  |
| DC              | Green  | Indicates the battery is supplying the power. At 45% battery capacity, the LED will flash and then alarm will beep 4 times per minute. |
| MUTE            | Orange | Press and hold the button "Alarm Silence" for 0.5 second to silence the audible alarm for 24 hours, and the LED will flash.            |
| REPLACE BATTERY | Red    | Battery replacement required. Alarm will beep once every 15 minutes. The LED also illuminates when battery is absent.                  |

- If the above lights are not as indicated please check following:
  - The power cord is plugged in
  - Circuit breaker is not tripped
  - GFI outlet is working properly and not tripped
- If the backup unit was unplugged the battery light may be red until fully charged.
- Internet port to is disabled when the CyberPower is unplugged from its power source

To Contact support please call 605-696-HELP (4357)